

Slackware installation using a serial terminal on an embedded system

I'll describe here what steps are required to install Slackware to a machine, using a serial terminal. The boot medium used here is a usb-key, but I think that these steps could be customized for booting from a CD-ROM (or PXE). I installed to a PC Engines APU (<http://www.pceengines.ch/apu.htm>), but most of these steps should be compatible for other systems. I've noted things special for this machine.

Prerequisites

- Machine with a serial port you want to install to
- Machine with a serial port you use to install the other machine
- A cable between them ;)
- `usbboot.img` from `slackware(64)?-$version/usb-and-pxe-installers/`

Preparation of the boot image

To install using a serial line, `syslinux` on the boot image must be configured to use the serial line for the menu itself and also append the right parameters to the booted kernel. To do this, mount the `usbboot.img` somewhere like this:

```
# mount -o loop usbboot.img /mnt/tmp
```

Now that the image is mounted, you can change the `syslinux.cfg` found in `/mnt/tmp`. Insert as a first line:

```
serial 0 115200
```

This enables the serial line for `syslinux` with 115200 bauds (parity and stopbit are hardcoded to n8). While the bootloader is now using the serial, the kernel still doesn't. Add

```
console=ttyS0,115200
```

To the append-line of the first kernel image (`huge.s`).



I have had problems with the keyboard input in `syslinux` using the serial line. To speed the things up you can set another timeout (in s/10) after which the default image (`huge.s`) is booted.

When you are done with the changes, you can unmount the image as usual. Like [recommended by Eric](#) install the `syslinux` bootloader to the image:

```
$ syslinux -s usbboot.img
```

The image is ready now to be dd'd onto a usb-key:

```
# dd if=usbboot.img of=/dev/myusbkey
```

Installation

Connect the serial ports of your two machines with a null-modem cable, and run

```
minicom -D /dev/ttyS0 -b 115200
```

on the machine you will use as your terminal. Now boot the machine you are installing Slackware to from the usb-key. You should see the usual booting on the terminal screen including the key map selection. After you have logged in as root, partition your disks as you would normally do.



APU special: You should also format and set a label to your partitions so that they show up in `/dev/disk/by-label`, it makes stuff a lot easier later e.g:

```
# mke2fs -L root /dev/sdb1
```

Don't let the Slackware installer format them then of course.

Before you run setup run this command to get a nicer looking output from dialog:

```
export DIALOGOPTS="--ascii-lines"
```

The rest of the installation should work as usual ("special" keys like page up don't seem to work correctly though..). But instead of rebooting after the installation has finished, we need to set the installed system to also use the serial line. Chroot into the installation:

```
# chroot /mnt
```

Now edit your `/etc/lilo.conf` and insert a line

```
serial= 0,115200n8
```

right at the top. The global append line needs the addition like the one used for the `usbboot.img`:

```
console=ttyS0,115200
```

to let it come up before the init system tries to mount it.



APU special: If you have installed onto a usb medium (the SD-card reader on the APU is connected by usb) you should also add:

```
rootdelay=10
```

The device order on the APU is likely to change. So you should `/dev/disk/by-label` or `/dev/disk/by-uuid` paths for your root partition statements in `/etc/lilo.conf`.



Furthermore you'll have to generate an `initrd` so that the device drivers for the card reader are available at boot time. Here also use a `/dev/disk/by-label` or `/dev/disk/by-uuid` path cause of the changing device order.

If you want to reinstall lilo after the installation, you probably also have to change the `boot=` device.

Save the lilo configuration and reinstall lilo. But don't reboot now, one more step before we are finished!

Uncomment the line enabling serial login in your `inittab` and change the speed to 115200:

```
[...]
# Local serial lines:
s1:12345:respawn:/sbin/agetty -L ttyS0 115200 vt100
[...]
```



Uncomment `ttyS0` in `/dev/securetty` or you will not be able to login as root from the serial line!

This should be all. Exit the `chroot` and reboot your system!

[howtos](#), [serial](#), [installation](#)

From: <https://docs.slackware.com/> - **SlackDocs**

Permanent link: https://docs.slackware.com/howtos:hardware:serial_installation

Last update: **2014/06/27 18:11 (UTC)**

