

Making it easy for u-boot to find ulmage and uinitrd

I often fiddle with testing root images, kernels and initrd on my kirkwood based systems by using usb flash sticks. I found that although Jeff did a brilliant job on uboot, at the time I started fiddling with custom boot images on my dosckstar, his default environment was unable to directly boot all my testing images that were rapidly changing in layout. To work around this I started making changes to his environment.

I made myself a custom environment that was more flexible and allowed me to boot from any usb port as long as the following limitations are met:

- the kernel must be called ulmage or must be linked with that name
- the initrd must be called uinitrd or must be linked with that name
- ulmage and uinitrd must be contained in the first 4 detected usb devices
- ulmage and uinitrd must be in the root or in a boot sub-directory in the device that holds them
- the root filesystem must be labelled “root” and should possibly be ext3 formatted

Heres the environment dumped from fw_printenv: (taken from my GoFlexNet)

```
arcNumber=<put here your device's correct arcNumber>
baudrate=115200
boot_flash_kernel=nand read $flash_kernel_load_addr $flash_kernel_offset
$flash_kernel_size; bootm $flash_kernel_load_addr
bootargs=console=ttyS0,115200 mtdparts=orion_nand:1M(u-
boot),4M(uImage),32M(rootfs),-(data) root=/dev/sda2 ro rootfstype=ext2
bootcmd=run usb_scan; run set_flash_bootargs; run boot_flash_kernel
bootdelay=3
console=console=ttyS0,115200
ethact=egiga0
ethaddr=<put here your mac address>
flash_kernel_load_addr=0x6400000
flash_kernel_offset=0x100000
flash_kernel_size=0x300000
flash_root_fs=root=/dev/mtdblock2
flash_root_fstype=rootfstype=jffs2
led_error=orange blinking
led_exit=green off
led_init=green blinking
mainlineLinux=yes
mtddids=nand0=orion_nand
mtdparts=mtdparts=orion_nand:1M(u-boot),4M(uImage),32M(rootfs),-(data)
partition=nand0,2
root_fs=root=LABEL=root
rootfstype=rootfs=ext3
sb_scan_1=usb=0:2 dev=sda2
set_flash_bootargs=setenv bootargs ${console} ${mtdparts} ${flash_root_fs}
ro ${flash_root_fstype}
set_usb_bootargs=setenv bootargs ${console} ${mtdparts} ${root_fs} ro
```

```
 ${root_fstype}
 stderr=serial
 stdin=serial
 stdout=serial
 usb_boot_6=setenv root_fs root=/dev/sdg${usb_dev_part}
 usb_dev_list=3 2 1 0
 usb_dev_part=1
 usb_part_list=4 3 2 1
 usb_scan=usb start; setenv usb_boot_dev none; for dev in $usb_dev_list; do
 test $dev -eq 0 && setenv devname /dev/sda ; test $dev -eq 1 && setenv
 devname /dev/sdb ; test $dev -eq 2 && setenv devname /dev/sdc ; test $dev -
 eq 3 && setenv devname /dev/sdd ; echo $devname ; for part in
 $usb_part_list; do echo $dev $part ; if ext2load usb ${dev}:$part 0x800000
 /boot/uImage 10 ; then setenv usb_boot_dev $dev:$part ; setenv usb_boot_dir
 /boot ; fi ; if ext2load usb ${dev}:$part 0x800000 /uImage 10 ; then setenv
 usb_boot_dev $dev:$part ; setenv usb_boot_dir ; fi ; done; done; if test
 "$usb_boot_dev" = "none" ; then echo "No USB bootable device found" ; else
 echo "USB device $usb_boot_dev is bootable" ; setenv bootargs $console
 $mtdparts $root_fs ro $rootfstype ; echo $bootargs ; sleep 1; ext2load usb
 $usb_boot_dev 0x800000 $usb_boot_dir/uImage && setenv usb_boot_address
 0x800000 ; ext2load usb $usb_boot_dev 0x1100000 $usb_boot_dir/uinitrd &&
 setenv usb_boot_address 0x800000 0x1100000 ; bootm $usb_boot_address ; fi;
```

Labeling the root filesystem was a workaround when I started getting issues on device namings changes as I began using the SATA drives for NAS storage. In practice what was happening was that uboot thought that root was on sda but once the kernel booted it would detect the SATA drives before that and name the usb memory stick to after the last SATA drive causing a kernel panic as initrd attempts to mount the root filesystem. I thus changed the u-boot environment to pass the root device as a label rather then a device path. This allows me to boot my GoFlexNet correctly from any usb stick (even trough a usb hub) regardless of the presence of the SATA drives.

To my understanding the latest uboot environments actually do more then this now ... so here's my last hybrid environment:

```
arcNumber=3089
baudrate=115200
bifsload=0x800000 /boot/$kernel && ubifsload 0x1100000 /boot/$initrd; then
bootm 0x800000 0x1100000; fi
bootargs=${{console} ${mtdparts} ${root_fs} ro ${rootfstype}}
bootcmd=usb start; run force_rescue_bootcmd; run ubifs_bootcmd; run
usb_scan; usb stop; run rescue_bootcmd; run pogo_bootcmd; reset
bootdelay=3
console=ttyS0,115200
ethact=egiga0
ethaddr=xx:xx:xx:xx:xx:xx
force_rescue=0
force_rescue_bootcmd;if test $force_rescue -eq 1 || ext2load usb 0:1
0x1700000 /rescueme 1 || fatload usb 0:1 0x1700000 /rescueme.txt 1; then run
rescue_bootcmd; fi
initrd=uinitrd
```

```
kernel=uImage
led_error=orange blinking
led_exit=green off
led_init=green blinking
mainlineLinux=yes
mtdid=0=nand0=orion_nand
mtdparts=mtdparts=orion_nand:1M(u-boot),4M(uImage),32M(rootfs),-(data)
partition=nand0,2
pogo_bootcmd=if fsload uboot-original-mtd0.kwb; then go 0x800200; fi
rescue_bootcmd=if test $rescue_installed -eq 1; then run
rescue_set_bootargs; nand read.e 0x800000 0x100000 0x400000; bootm 0x800000;
else run pogo_bootcmd; fi
rescue_installed=0
rescue_set_bootargs=setenv bootargs console=$console ubi.mtd=2
root=ubi0:rootfs ro rootfstype=ubifs $mtdparts $rescue_custom_params
root_fs=root=LABEL=root
rootfstype=rootfs=ext3
safearcNumber=2097
setbootargs=setenv bootargs console=${console} ${mtdparts} ${root_fs} ro
${rootfstype}
stderr=serial
stdin=serial
stdout=serial
ubifs_bootcmd=run ubifs_set_bootargs; if ubi part data && ubifsmount rootfs
&& ubifsload 0x800000 /boot/uImage && ubifsload 0x1100000 /boot/uInitrd;
then bootm 0x800000 0x1100000; fi
ubifs_mtd=3
ubifs_set_bootargs=setenv bootargs console=$console ubi.mtd=$ubifs_mtd
root=ubi0:rootfs rootfstype=ubifs $mtdparts $ubifs_custom_params
usb_dev_list=3 2 1 0
usb_part_list=4 3 2 1
usb_rootdelay=10
usb_scan=sleep 5; setenv usb_boot_dev none; for dev in $usb_dev_list; do for
part in $usb_part_list; do if ext2load usb ${dev}:$part 0x800000
/boot/$kernel 10; then setenv usb_boot_dev $dev:$part; setenv usb_boot_dir
/boot; fi; if ext2load usb ${dev}:$part 0x800000 /$kernel 10; then setenv
usb_boot_dev $dev:$part; setenv usb_boot_dir ; fi; done; done; if test
"$usb_boot_dev" = "none"; then echo "No USB bootable device found"; else
echo "USB device $usb_boot_dev is bootable"; run setbootargs; echo
$bootargs; sleep 1; ext2load usb $usb_boot_dev 0x800000
$usb_boot_dir/$kernel && setenv usb_boot_address 0x800000; ext2load usb
$usb_boot_dev 0x1100000 $usb_boot_dir/$initrd && setenv usb_boot_address
0x800000 0x1100000; bootm $usb_boot_address; fi;
```

Sources

[howtos](#), [arm](#), [author](#) , louigi600

From:
<https://docs.slackware.com/> - **SlackDocs**



Permanent link:
https://docs.slackware.com/es:howtos:hardware:arm:sone_u-boot_hints

Last update: **2019/03/17 23:45 (UTC)**