Slackware ARM project web site | Forum | Slackware ARM development documentation | Slackware ARM installation guides

## Installing Slackware on the Raspberry Pi

Platform	AArch64/ARM64
Hardware Model	Raspberry Pi 4/400
Document Version	1.06, Mar 2024
Author	Stuart Winter <mozes@slackware></mozes@slackware>
Contributors	Brenton Earl <el0226@slackware> (R&amp;D for the RPi4 Hardware Model)</el0226@slackware>

#### **Supported Raspberry Pi versions**

At the moment, only the Raspberry Pi 4 is officially supported.

The Raspberry Pi 400 has been validated as working by the user community.

### Video Tutorial

111

This tutorial is also available in video form.



The video tutorial demonstrates the original installation approach where the Slackware installation media was separate. A single Slackware Installer image is provided that contains all of the media, so it's easier than shown in the video.

#### Help / Support

Please post questions to the Slackware ARM forum.

#### Caveats

#### Fragility due to upstream support

The support within the proper Linux Kernel is fragile due to the development model of the Raspberry Pi company. You may need to switch to the RPi Kernel fork for the best experience. Instructions on how to do this are included in the post installation section of this document.

#### Installation Lifecycle

\_\_\_\_\_

The Installation consists of a number of distinct stages:

- 1. Acquiring all required hardware
- 2. Setup of the Raspberry Pi hardware
- 3. Downloading and Verifying the Slackware assets
- 4. Writing the Slackware Installer to the Micro SD card
- 5. Booting the Slackware Installer
- 6. Installing Slackware
- 7. Completing the installation
- 8. Booting the Slackware OS
- 9. Post installation configuration and tweaks

## Requirements

#### Hardware



This hardware list is what has been recommended by the Slackware community as a good starting point for setting up a Raspberry Pi. There are a plethora of peripherals available for the Raspberry Pi which you can use with Slackware.



SD cards: Some SD cards are known to have issues on the Raspberry Pi4. Please use one of the brands provided in the hardware table below.



Please purchase the hardware from any vendor: Slackware ARM has no affiliation with The PiHut, but it is a useful one-stop-shop for RPis and accessories, and this author can attest to good service within the UK.

ltem	Specification/Type	Required?	Notes
Raspberry Pi 4 Model B	4GB and 8GB RAM models have been tested	Yes	This is the bare board
'Ice Tower' CPU heat sink & cooling fan		A heat sink or CPU is required	This has been recommended as a suitable fan for high-CPU workloads.
Power supply	Official Raspberry Pi PSU	Yes	It's best to use the official PSU as others can cause instability over time.
Inline power switch	-	Optional but recommended	The Raspberry Pi 4 does not have reset nor power buttons on the board. Reports from the Slackware community suggest that the power socket on the Rpi will become damaged over time from wear. This inline power switch prevents damage to the RPi.

Item Specification/Type		Required?	Notes
Micro to full- size HDMI adapter	-	Optional	Depends on your local setup and whether you wish to connect an HDMI monitor to the RPi.
Real Time Clock (RTC)	Adafruit PiRTC - Precise DS3231	Optional	This RTC been recommended by the Slackware community.
Battery for RTC	Lithium 3volt CR1220	Optional	Depends on whether you use the RTC module. This enables the RTC to maintain the time whilst the RPi is powered down.
Dupont wires	Female to male	Optional	This is to wire in the RTC module, as the large sized CPU heat sink prevents the RTC module from connecting directly to the GPIO. These wires are also useful for connecting other peripherals to the RPi's GPIO.
SATA storage / SSD	Minimum useful size: 30GB	Required	Will contain the Operating System. You can install to other storage, but this documentation covers this particular configuration only. The Kingston- SA400S37-240G has thoroughly proved itself in the Slackware ARM build infrastructure - most build machines use these, but any SSD or spinning hard disk should work
USB to SATA adapter	-	Required	Many models will work, but this one has been tested on many of this author's ARM hardware.
USB to Serial adapter	PL2303 chip. Other models may work, but this one has been tested. If your model has the option to set voltages, ensure <b>3volts</b> is set!	Optional	A USB to Serial/UART adapter is recommended if you want to access the console remotely, but is unnecessary if you only plan on using an HDMI monitor. This document covers installing using an HDMI monitor - you can find information about connecting the Serial/UART adapter at the foot of this document
Micro SD Card	16GB <b>minimum</b> <b>capacity</b> , Class 10 (fast speed)	Required	Initially used to boot the Slackware Installer, and subsequently transformed into Slackware's /boot partition.
USB keyboard and mouse	Standard peripherals	Required	A USB keyboard and mouse are required for this Slackware installation guide but are not required for the running of the OS. Slackware can also be installed headless (without a keyboard or monitor) over the Serial/UART or SSH (but this isn't documented).

#### Recommended/ tested SD cards and other storage peripherals

In addition to the examples of tested hardware, here follows other storage devices and peripherals that have been tested by the Slackware community.

Туре	Details
Micro SD card	Gigastone 32GB
Micro SD card	Kingston 64GB microSDHC Canvas Select Plus
Micro SD card	Kingston SDCG3

Туре	Details
Micro SD card	SanDisk 16GB
USB to SATA adapter (alternative to the one in the table above)	SKL Tech

#### Alternatives to SSD

If you prefer to use NVME storage, these have been tested:

NVME Storage Module	Kingston A2000 SSD 250G & 500GB models
USB to NVME M.2 adapter &	LEMORELE M.2 NVMe SSD Enclosure USB C External PCIe B+M/M-
enclosure	Key SSD Caddy 10Gbp UASP USB 3.1 Gen 2 M2

#### Notes on storage setup

The setup documented here (2.5" SSD connected to a USB-to-Serial adapter for power and data) has proven stable for this author.

It is possible to create a 4th partition on the Micro SD card ('MMC') which can house the Slackware OS. However, this is not recommended due to the longevity of this type of storage - particularly if it has high I/O. If you want to install the OS to the MMC card, it's preferable to use the "bare" Slackware Installer image rather than the standard 'AiO' (All in One) Installer (which is what this Installation guide covers). Using the bare Installer means you will need to install over the network or from some locally attached storage.

#### **Computing / Network Environment**

Item	Specification	Notes
	The Host Computer needs	This will be used to download
Host Computer: an Internet-	approximately <b>5GB free storage</b> to	the Slackware distribution
connected computer running	download the required software	from the Internet and to write
an existing Linux distribution	assets. You must be able to obtain	the Slackware Installation
	root access to this Host computer.	media to the Micro SD card.

## **Hardware Setup**

In this section we'll prepare the physical aspects of the Raspberry Pi4 to receive Slackware Linux.

Note that this is just one of a vast array of hardware configurations for the Raspberry Pi4. If you have a different configuration that's already working, you can skip to the 'Software and Network Environment Setup ' section

#### Attach the base board

Attach the base board to the RPi4 using the brass spacers. Ensure that each brass spacer is screwed

into the base board, as shown.



The base board comes with the 'Ice Tower' CPU cooling pack (as mentioned within the Hardware Requirements table). Other RPi "open" case designs would connect the RPi in a similar manner (e.g., the bottom element of Micro Connectors' Acrylic Stackable Raspberry Pi case)

#### Screw four spacers to the top to secure the board to the platform



#### Attach the thermal tape to the CPU

Lay one of the pieces of thermal tape atop the CPU as shown:

Last update: 2024/04/30 14:59 slackwarearm:inst\_sa64\_bcm2711\_rpi4 https://docs.slackware.com/slackwarearm:inst\_sa64\_bcm2711\_rpi4



#### Attach the heat sink brackets



Pay close attention to the positioning of the brackets, otherwise it won't sit on the board properly.



Use the symbols on the brackets for orientation

#### Secure the board to the platform

2024/05/01 11:19 (UTC)

7/40



Only apply 3 nuts as shown. The fourth brass-coloured 'spacer' will be used to seat the RTC (Real Time Clock). If you do not have an RTC, secure this with a fourth nut.

#### Attach CPU fan power wires



**RTC (Real Time Clock): Insert battery** 

Last update: 2024/04/30 14:59 slackwarearm:inst\_sa64\_bcm2711\_rpi4 https://docs.slackware.com/slackwarearm:inst\_sa64\_bcm2711\_rpi4



**RTC (Real Time Clock): Wiring** 



Empty front pins Connect to: GPIO pin 34

(GND)

For your orientation 9/40



#### RTC (Real Time Clock): Attach to Raspberry Pi



Last update: 2024/04/30 14:59 slackwarearm:inst\_sa64\_bcm2711\_rpi4 https://docs.slackware.com/slackwarearm:inst\_sa64\_bcm2711\_rpi4



#### Add all other peripherals required to install Slackware

- Connect the storage ensure that it's connected to a **blue USB 3.0** port
- Connect the Ethernet cable (optional required if you want to set the date via NTP before commencing installation)
- Connect the HDMI cable
- Connect the USB keyboard and mouse



The basic hardware setup is complete.

## **Downloading the Slackware assets**

In this section, we'll prepare the Linux Host Computer to receive and download the Slackware assets required for the installation.

#### **1.** Downloading the Slackware Linux AArch64 Distribution and Installation Assets



The '\$' prefixes in the commands indicates the shell prompt - it's not to be typed/copied

Open a shell on the Linux Host Computer.

#### Prepare a directory to hold and serve the Slackware Distribution

We'll download the Slackware Linux distribution into a directory named 'slackware'.

\$ cd ## this returns to the root of your home directory
\$ mkdir slackware
\$ cd slackware

#### Determine where you are within the Host Computer's Filesystem

\$ pwd
/home/mozes/slackware

(!)

Note the directory location returned - you'll need this later

#### Installing the Slackware ARM GPG key

The Slackware ARM GPG key will be used to verify your downloads.

\$ curl -sSL https://www.slackware.com/infra/keys/arm/GPG-KEY | gpg --import

#### Set the model of Raspberry Pi

The Raspberry Pi Slackware Installer images are identical, so if you have both the RPi3

note



& 4 you should only download one image. If this changes, this message will be removed.

#### For the Raspberry Pi 3:

\$ HWM=bcm2837\_rpi3

For the Raspberry Pi 4:

\$ HWM=bcm2711\_rpi4

#### Set the version of Slackware AArch64 to download

At the time of writing, the only version available is 'current'.

#### \$ SLKVER=current

#### Set the Internet media distribution server

If you are using a mirror server rather than the master Slackware ARM server, set it here. The format is: <hostname>::<rsync module name>

```
$ SLKSRV=ftp.arm.slackware.com::slackwarearm
```

#### **Download the Slackware Linux Installer**

```
$ rsync -PavL $SLKSRV/platform/aarch64/bootware/installer-
aio/slackwareaarch64-${SLKVER}/${HWM}.img.xz.asc slkaio.img.xz.asc
$ rsync -PavL $SLKSRV/platform/aarch64/bootware/installer-
aio/slackwareaarch64-${SLKVER}/${HWM}.img.xz slkaio.img.xz
```

The Slackware Installer images are approximately 5 GBytes in size.

#### Verify the Slackware Installer image

Verify the digital signature of the Slackware Installer:

\$ gpg --verify slkaio.img.xz.asc

As the images are large, verification may take a minute or two.

The output will be similar to this. You are looking for 'Good signature from Slackware ARM...'

note

Last update: 2024/04/30 14:59 slackwarearm:inst\_sa64\_bcm2711\_rpi4 https://docs.slackware.com/slackwarearm:inst\_sa64\_bcm2711\_rpi4

```
gpg: assuming signed data in `slkaio.img.xz'
gpg: Signature made Wed 24 Nov 2021 06:07:44 PM BST
gpg: using RSA key F7ABB8691623FC33
gpg: Good signature from "Slackware ARM (Slackware ARM Linux Project)
<mozes@slackware.com>" [unknown]
gpg: WARNING: This key is not certified with a trusted signature!
gpg: There is no indication that the signature belongs to the
owner.
Primary key fingerprint: 36D3 7609 2F12 9B6B 3D59 A517 F7AB B869 1623 FC33
```

If you see 'BAD signature' you should re-download as it may have become corrupt. If this doesn't help, drop a note to the Slackware ARM forum

## Writing the Slackware assets to the Micro SD

#### Elevate yourself to root

On your Host Computer, obtain root:

The # prefix indicates that you're using the **root** user - it's not to be typed in!

\$ su - ## Note the hyphen - it's required

#### Write the Slackware Installer to the Micro SD card

#### Check what block devices are present

Prior to inserting the Micro SD Card into the USB adapter, we need to see what's already present within the OS so that we can easily locate our Micro SD card:

# lsblk -d
NAME MAJ:MIN RM SIZE RO TYPE MOUNTPOINTS
sda 8:0 0 465.8G 0 disk

As you can see, this Host Computer there is a single storage device - *sda*.

Insert the Micro SD card into your USB Card Reader and connect the adapter to a free USB port on the Host Computer

Run Isblk again:

# lsbl	k-d					
NAME	MAJ:MIN	RM	SIZE	R0	TYPE	MOUNTPOINTS
sda	8:0	0	465.8G	0	disk	
sdc	8:32	1	58G	0	disk	
sdd	8:48	1	0B	0	disk	

As you can see, *sdc* is 58 GBytes in size. This is the Micro SD card (in this example, it's labeled as '64GB' on the exterior of Micro SD card).

If your Micro SD card has existing partitions, you will not see them surfaced in this list - use *lsblk -b* to view them.



You'll also observe the presence of *sdd* - often the USB adapter itself obtains a block device. You can ignore this as it's 0Bytes.

#### Write the Slackware Installer to the Micro SD card

Enter the directory into which the Slackware assets were downloaded previously:

```
# cd ~mozes/slackware ## Substitute with the path you noted earlier
# xzcat slkaio.img.xz | dd status=progress bs=4M iflag=fullblock of=/dev/XXX
## Substitute/dev/XXX with the correct block device
# sync
```

#### Remove the MicroSD card from the Host Computer

You may now disconnect the USB adapter/remove the Micro SD card from the Host Computer.

#### Logout from the root user

We no longer need to use the Host Computer, so you can logout of the root shell.

# logout

## **Installing Slackware**

To proceed, you must have:

- Connected the storage to the Raspberry Pi 4
- Connected the HDMI monitor
- Connected the keyboard (and optionally, mouse)
- Optionally connected the Ethernet cable to set the date via NTP from the Internet
- Inserted the Micro SD card containing the Slackware Installer

Last update: 2024/04/30 14:59 (UTC)

#### **Encrypted storage**

If you'd like to encrypt your storage, check the Disk Encryption Guide.

#### **Begin installation**

Disconnect any USB storage devices that aren't required for the OS installation



Due to bugs in the upstream Linux Kernel, the screen may blank every few seconds. This is normal and can be resolved by switching to the Raspberry PI Kernel fork (detailed later in this guide).

#### Power on the Raspberry Pi 4

Apply power to the Raspberry Pi and after a few seconds, you will see the following on screen:



It takes several seconds to load and boot the installer, and it may take several seconds more for any further output to appear on the HDMI monitor. The process of obtaining an IP address via DHCP can also delay the ability to interact with the Installer.

Once an IP address has been obtained, you will be presented with a prompt. Press ENTER



Set the keymap



OK, the new map is now installed. You may now test it by typing anything you want. To quit testing the keyboard, enter 1 on a line by itself to accept the map and go on, or 2 on a line by itself to reject the current keyboard map and select a new one.

#### 1

#### Font size

If you're using a smaller monitor, such as one with a screen size less than 20 inches, it may be necessary to adjust the console font size to ensure that menus and other interface elements fit correctly on the screen. If so, type this into the shell prompt:

setfont ter-v18n

#### Set the date/time

Even if you have a battery pack for the RTC (Real Time Clock), the date on your system may be incorrect. We will sync the date from a highly-available NTP server:

ntpdate clock.akamai.com

Last update: 2024/04/30 14:59 slackwarearm:inst\_sa64\_bcm2711\_rpi4 https://docs.slackware.com/slackwarearm:inst\_sa64\_bcm2711\_rpi4

hwclock -w



#### Setup disk partitions

For this installation a basic partitioning scheme will be created.

Partition

Partition number	Device name	Size	Purpose
1	/dev/sda1	4GB	Swap
2	/dev/sda2	Rest of storage	OS root ('/') partition



Open fdisk against the /dev/sda block device. In this guide, /dev/sda will be your primary storage, and in this guide is the SSD connected to the USB adapter.

#### fdisk /dev/sda



Clear an existing partition table: Press 'o' to clear the partition table

Command (m for help): o Created a new DOS disklabel with disk identifier 0xc32fb51d.

Create the Swap partition:

Type 'n' for new partition:



Type 'p' for primary partition type:

Press ENTER for the 'First sector'

Type '+4G' for the 'Last Sector'/size:

Change the partition type to 'Swap'. Type 't' then hex code '82':



Create the partition for the root filesystem ('/'):

Type 'n' for new partition. Press ENTER to accept the defaults - this will create partition 2 as the maximum size available.



Type 'a' to mark the root partition (number 2) as bootable Type '2' to select partition 2.



Type 'p' to print to view the partition table.

Command (m Disk /dev/ Disk model	for i sda: i : SA	help): p 223.57 G 400S37244	i <b>B, 240057</b> 4	409536 byt	es, 468	862	128 se	ctors
Units: sec	tors	of 1 * 5	12 = 512 by	rtes				
Sector siz	e (lo	gical/phy	vsical): 5	12 bytes /	512 by	tes		
I/O size (	minim	um/optim	al): 512 by	ytes / 335	53920 b	yte	5	
Disklabel	type:	dos						
Disk ident	ifier	: 0x9feb	5c33					
Device	Boot	Start	End	Sectors	Size	Id	Type	
/dev/sda1		2048	8390655	8388608	4G	82	Linux	swap
/dev/sda2	*	8390656	468862127	460471472	219.6G	83	Linux	

Type 'w' to write the partition table:



fdisk will now exit.

#### Load the Setup menu



#### **Setup Swap partition**









#### Select and format the partition for the OS' root file system





#### SELECT FILESYSTEM FOR /dev/sda2

Please select the type of filesystem to use for the specified device. Here are descriptions of the available filesystems: Ext2 is the traditional Linux file system and is fast and stable. Ext3 is the journaling version of the Ext2 filesystem. Ext4 is the successor to the ext3 filesystem. Btrfs is a 8-tree copy-on-write filesystem. FZFS is a Flash-Friendly File System. JFS is IBM's Journaled Filesystem, currently used in IBM enterprise servers. ReiserFS is a journaling filesystem that stores all files and filenames in a balanced tree structure. XFS is SGI's journaling filesystem that originated on IRIX.





#### **Boot Loader Configuration**

The Installer will configure the Boot Loader and the OS' /etc/fstab automatically:



On the ARM platform, the Swap and root file systems are addressed by labels (*see above: 'LABEL='*) where as on x86/64 it's addressed by a direct reference to the block device (e.g. /dev/sda). The Slackware Installer will label swap partitions as '*SLKswap*<*x*>', and the root file system '*SLKroot*'. Other labels in use are '*SLKboot*' for the OS boot partition (/boot), and '*SLKhwm\_bw*' for the Hardware Model Bootware partition (/boot/platform/hwm\_bw). These labels are pre-labeled on the SD card image that you deployed and won't be presented during the installation process.

The rationale behind this divergence is that on x86 the root file system is typically on a storage bus (SCSI, SATA, ATA), where the physical configuration (which port the storage is connected to) of the storage rarely changes. This can be the case on ARM, but it's generally to a lesser extent and the root file system may be connected to a hot-plug bus such as USB. This lends itself to the risk of device re-ordering across boot cycles (e.g. /dev/sda becomes /dev/sdb), causing boot failure.

P

Please be aware that the Slackware Installer *only* labels the swap and root file system. Therefore you are advised to manually label the file systems and modify the OS /etc/fstab accordingly. If you have only a single storage device and don't plan on adding more, you can use the settings that the Slackware Installer configures.

#### Select Source Media



Press ENTER to say 'Yes'.

If you would like to install from an alternate media source, pick 'No' and you will be presented with options to install over NFS, USB and HTTP amongst others.

Ordinarily you should always say 'Yes' unless you've been directed to do otherwise.

#### **Package Series Selection**

You can now choose the package sets to install. The recommendation is to install everything. A full Slackware installation will occupy approximately 15GB.



If you do not plan to use the graphical window manager such as KDE, you should deselect it.



#### Pick the 'terse' option:



#### The packages will begin installing:

>> Installing package series A	
wa_base-15.0-aarch64-1: Wasic Linux filesystem package	80K
ww.glibc-solibs-2.33-aarch64-3: shared GMU C libraries	[ 120]
aa_libraries-15.0-aarch64-7: shared libraries needed by many programs	200
aa_terminfo-6.3-aarch64-1: a basic collection of terminfo entries	[ 198K]
cl-2.3.1-aarch64-1: tools for using POSIX Access Control Lists	388K
cpid-2.0.33-aarch64-1: ACPI downon	170K
ttr-2.5.1-ourch64-1: tools for using extended attributes on filesystems	250K
ash-5.1.008.000-aarch64-1: sh-compatible shell	[ 8.3M
in-11.1-march64-5: some command-line utilities	180K
trfs-progs-5.15-aarch64-1: Btrfs filesystem utilities	4.7M
zip2-1.8.8-aarch64-3: a block-sorting file compressor	[ 190K]
oreutils-9.0-oarch64-1: core GNU utilities	17M
pio-2.13-aarch64-3: backup and archiving utility	1.34
pufrequtils-008-aarch64-4: Kernel CPUfreq utilities	[ 170K]
racklib-2.9.7-aarch64-2: passward checking library	1.14
ryptsetup-2.4.1-aarch64-1: utility for setting up encrypted filesystems	2.64
bus-1.12.20-aarch64-4: D-Bus message bus system	[ 1.8M
Icron-4.S-aarch64-7: Dillon's Cron daemon	110K
evs-2.3.1-march64-2: system device files	5.04
ialog-1.3_20211107-aarch64-1: display dialog boxes from shell scripts .	510K
osfstools-4.2-aarch64-2: tools for working with FAT filesystems	310K
2fsprogs-1.46.4-aarch64-1: ext2/3/4 filesystems utilities	5.9M

#### **Configure the Console Settings**

If you plan on using the UART/'Serial' console, you should select 'No' here. If you plan on exclusively using an HDMI monitor, you should pick 'Yes'.



This setting can be reset to the default by editing /boot/extlinux/extlinux.conf and removing the 'console=' setting once the OS has booted.

	CONFIGURE CONSOLE SETTINGS
You may no	w configure the console settings of your Rospberry Pi 4 Model B
If you do direct all monitor/LC If you hav	not plan to use the UART ('Serial Console'), you may wish to Kernel and Operating System output to the virtual consoles (HDM D panel). This setting precludes the use of the UART, we no intention of using the UART, you should select 'Yes'.
If you wil should sel both the v virtual co	l use the UARY for debugging/developing or remote access, you act 'No'. This is the safest setting and enables console access rideo and UART, but the boot messages will be split between the msole and UART. Usually this isn't a problem for most users.
These sett /boot/extl	ings can be changed later within the boot loader configuration: inux/extlinux.conf
Recomenda	rtion is "No'

#### Remove the Slackware Installer from the SD card

The Micro SD card is transformed from being the Slackware Installer into the Slackware OS's /boot partition. At this stage, if the installation has worked for you (at certain points in the Slackware installer you are past the point of no return) you can delete the Installer. However, if something has gone wrong you can reset the Raspberry Pi and reboot the installer without having to re-deploy the Slackware Installer image from your Linux Host Computer.

Generally you should say 'Yes' here.





You may be tempted to retain the Slackware Installer, but note that the Installer contains Linux Kernel modules for the Kernel that the Installer was originally shipped with. This means that as soon as you upgrade the Slackware Kernel package, the



Installer will fail to boot. The option to retain the Installer is present purely because on a number of occasions, this author only realised that the installation was incorrectly performed upon completion, and needed to reinstall. Retaining the Installer avoids the requirement to re-deploy the image to the SD card.

#### **Post Installation Configuration**

The Slackware Installer will walk you through the standard Slackware setup. The on-screen instructions will suffice.



pi			
	< 0K >	< Entra >	





w we need to know how your machine connects to the network. If you have an internal network card and an assigned IP address, gateway, and DNS, use the 'static IP' choice to enter these values. If your IP address is assigned by a DHCP server (commonly used by cable modem and DSL services), select 'DHCP'. Select 'NetworkManager' if you would like to have the NetworkManager doemon automatically handle your wired and wireless network interfaces (this is simple and usually works). IPv6 networks may also use SLAAC (Stateless Address Autoconfiguration) to assign an address based on Router Advertisments. If you do not have a network card, select the 'loopback' choice Which type of network setup would you like?



#### NETWORK SETUP COMPLETE

Your networking system is now configured to use NetworkManager for wired and wireless network management. To set up wireless networks and view status, add the Network Management control panel widget to your desktop.

Is this correct? Press 'Yes' to confirm, or 'No' to abandon.

< es >

#### CONFIRM STARTUP SERVICES TO RUN

< 141 >

The selected services will be started at boot time. If you don't need them, you may unselect them to turn them off (which may improve overall system security). You may also choose to start services that are not run by default, but be aware that more services means less security. Use the spacebar to select or unselect the services you wish to run. Recommended choices have been preselected. Press the ENTER key when you are finished.



#### Select a Console Font

It's recommended for the Raspberry Pi that a larger console font is configured for the virtual console.

Last update: 2024/04/30 14:59 slackwarearm:inst\_sa64\_bcm2711\_rpi4 https://docs.slackware.com/slackwarearm:inst\_sa64\_bcm2711\_rpi4





The recommended font is 'ter-732b.psf'. This is the font used within the Installer.



#### **Continue Post Installation Configuration**







#### **Configure GUI Window Manager**

This author recommends using XFCE as it's light weight versus KDE.



#### **Continue Post Installation Configuration**



#### Slackware Setup Complete



#### **Reboot into the Slackware OS**

Slackware Linux	Slockwore Linux Setup is complete setup is complete.
You may now rebo	oot your machine into the Slackware OS.
If you have some can open a shell	e post-installation tweaks you'd like to make manually, you l.
If you want to m Slackware OS, ye	make some changes to the hardware before booting the ou may wish to power off computer.
	Shell Roboot Power Off

Generally you'll want to reboot into the OS.

However, if you are planning on setting up RAID or need to customise the Operating System Initial RAM Disk, you should select 'Shell'.

The Slackware OS will be found within '/mnt'. You can use the 'os-initrd-mgr' tool (Video tutorial).

#### Booting the Slackware OS

![](_page_30_Picture_8.jpeg)

Login to the Slackware OS

![](_page_30_Picture_10.jpeg)

You may now login as 'root', using the password you set within the installer.

## **Post Installation Configuration**

There are a few post-installation configuration tasks to complete.

#### Initial Time/Date Sync

If Internet access is available to the Raspberry Pi, prior to proceeding with any further setup, you may wish to set the time now as a one-off event:

Elevate yourself to **root** and use **ntpdate**:

```
$ su -
# ntpdate rolex.ripe.net # or pick your favourite NTP server
# hwclock -w # writes the date to the RTC
# logout
```

#### NTP (Network Time Protocol) setup

Even if your Raspberry Pi has an RTC (as documented in this guide), you may wish to configure it to set time from an Internet NTP Server. The Raspberry Pi requires continuous Internet access for this to function.

#### Add a plebeian user

You should add a plebeian (non-root) user using the 'adduser' tool.

This is documented here.

#### **KDE** fixups

If you are using KDE, you need to first adjust a setting.

As your plebian user, **prior** to loading KDE, run this command.

![](_page_31_Picture_16.jpeg)

This will disable the *Compositing* feature. This is required when using the mainline Linux Kernel (as Slackware does).

kwriteconfig5 --file kwinrc --group Compositing --key Enabled false

You may now start KDE.

#### Use a graphical login manager

If you prefer to use a graphical login manager, you can configure the default runlevel as 4:

```
su -
sed -i 's?id:3:?id:4:?g' /etc/inittab
reboot
```

## Managing Slackware on the Raspberry Pi

## Keeping the Slackware OS up to date

One of the preferred tools to keep your system up to date is slackpkg.

![](_page_32_Picture_8.jpeg)

## Loading Additional Linux Kernel Modules within the OS Proper

Often Kernel modules for discovered hardware will be automatically loaded, but occasionally you will need to manually configure the loading of some modules.

/etc/rc.d/rc.modules.local

This file is a shell script that is run as one of the last steps before the OS has fully booted. You can enter modprobe commands here to load the specific modules you require.

Configuration files within the directory /lib/modprobe.d/ can be used to configure the parameters of the modules. Existing files within that directory serve as reference examples should you need them.

# Loading Additional Linux Kernel Modules early in the boot sequence

There are a number of peripherals that may require Kernel modules loading early on in the boot sequence. An example of this would be RTCs (Real Time Clocks) or storage controllers that are required to access the file systems on which the OS lives.

SlackDocs - https://docs.slackware.com/

![](_page_33_Picture_1.jpeg)

Usually you won't need to load modules early in the boot sequence. See the previous section about loading modules from within the OS Proper.

To load Kernel modules during the early boot sequence, read:

```
/boot/local/README.txt
```

As root, the easiest way to begin is by renaming the example script:

```
mv /boot/local/load_kernel_modules.post.sample
/boot/local/load_kernel_modules.post
```

Then add the appropriate module loading commands to: /boot/local/load\_kernel\_modules.post You can also add shell code here to initialise a peripheral - writing something to the peripheral's Kernel interface, for example.

## Slackware repository partition

The Slackware Installer image contains a type ext4 partition labeled SLKins\_aio-pkgs from which the packages are installed.

```
root@slackware:~# mount LABEL=SLKins_aio-pkgs /mnt/zip
root@slackware:~# cat /mnt/zip/README.txt
This file system contains the Slackware repository that is used during the
installation of Slackware.
Once you've booted into your OS you can delete or change this partition if
you
```

wish, or perhaps you might like to retain it for future reference.

root@slackware:~#

Most users simply leave the partition alone, as it causes no issues.

## **Customising the Slackware Linux Kernel**

If you'd like to customise the Linux Kernel, the easiest way is to follow the HOWTO guide and use the Slackware ARM Kernel build script to create new packages.

This document also covers using the Raspberry Pi Kernel fork (although this is not recommended).

## **Reducing Boot Time**

Slackware ARM ships with a generic OS InitRD (Operating System Initial RAM Disk - the environment that prepares the machine to boot the Operating System Proper), so as to support a wide range of Hardware Models.

However, this isn't the optimal setup once the Slackware OS has been installed because the generic OS InitRD typically exceeds 250MB, which in some cases can add several seconds to the boot time whilst it's loaded from the SD card.

The os-initrd-mgr (Operating System Initial RAM Disk Manager) tool has an option to synchronize the OS InitRD's Kernel modules with *only* those presently loaded within the Operating System.

To do this:

```
$ su -c 'os-initrd-mgr --sync-loaded-kmods' - # note the final -
```

![](_page_34_Picture_8.jpeg)

To have this setting persist across Kernel upgrades, you must upgrade the a/kernelmodules package before a/kernel. If not, it'll revert to the generic OS InitRD until you next reboot. If you are using slackpkg to manage upgrades, this is handled for you.

This option isn't the default, but you can make it so by following the instructions within /etc/os-initrd-mgr.conf.sample

This way when you upgrade the Kernel packages in the order described above, it'll automatically synchronize the modules.

os-initrd-mgr has a safety check to only proceed when the running Kernel and incoming Kernel are at the same major version and patch level.

![](_page_34_Picture_13.jpeg)

For example, when running Linux 5.17.1, upgrading to 5.17.2 will work; but an upgrade of Linux 5.17.1  $\rightarrow$  5.18.1 will require a reboot then to run os-initrd-mgr again to re-sync.

![](_page_34_Picture_15.jpeg)

## Managing the Raspberry Pi Firmware

![](_page_34_Picture_17.jpeg)

Do not use the rpi-update script (found in other distributions) - this is unnecessary

![](_page_35_Picture_1.jpeg)

The Raspberry Pi firmware is managed by the Slackware packages.

#### Bootware

The Raspberry Pi boots from a FAT partition on the Micro SD card. This partition contains the closedsource proprietary boot loader, firmware and various other assets it requires. It is mounted within the Slackware OS under /boot/platform/hwm\_bw (on other distributions these files reside within /boot).

These assets are provided and managed by the Slackware package a/hwm-bw-raspberrypi.

![](_page_35_Picture_6.jpeg)

#### Firmware for the EEPROM

The Slackware package a/hwm-bw-raspberrypi contains the available firmware that can be programmed to the Raspberry Pi's EEPROM.

You also need to have the a/rpi-userland package installed.

This firmware update requires manual action - see below

To update the firmware on your RPi's EEPROM; as root:

\$ rpi-eeprom-update -d

This will report if there's newer firmware available.

To update the firmware:

\$ rpi-eeprom-update -d -a

If the firmware was successfully updated, reboot:

\$ reboot

![](_page_35_Picture_18.jpeg)

The EEPROM tool configuration file is: /etc/rpi-eeprom-update. By default we're using firmware from the "critical" (most stable and well-tested) release channel, but you can change it within that configuration file.

#### **Raspberry Pi SoC/IP Core Firmware**

The firmware for the peripherals on the Raspberry Pi Hardware Models is contained within the Slackware a/kernel-firmware package.

![](_page_36_Picture_5.jpeg)

Simply upgrading to the latest available Slackware packages will update this firmware.

## **Using Device Tree Overlays**

Device Tree Overlays can be configured within the Raspberry Pi's Native Boot Loader configuration file: /boot/platform/hwm\_bw/config.txt

![](_page_36_Picture_9.jpeg)

Note: The Raspberry Pi's Native Boot Loader configuration is outside of the management of the Slackware OS so you need not be concerned with any automatic modifications.

#### Raspberry Pi 3: Enabling Blue Tooth

![](_page_36_Picture_12.jpeg)

The Raspberry Pi 3 requires that the serial connection be disabled in order to use Blue Tooth.

To do this you need to edit one setting:

#### Elevate yourself to 'root'

\$ su -

#### Configure the UART setting

\$ nano /boot/config.txt

Find the line: enable\_uart=1

Change it to: enable\_uart=0

Save the file and reboot.

## Switching to the Raspberry Pi Kernel fork

The Raspberry Pi's are only intended to run the vendor's own Linux distribution, or to run as an 'Appliance' using the Raspberry Pi Linux Kernel fork.

As a consequence, the upstream mainline Linux Kernel in which support for the Raspberry Pi is fragile and prone to breaking without notice. Slackware uses official upstream repositories/releases and has a no-patch policy. As such, the recommendation of using the vendor's own Kernel fork is far outside the scope of Slackware.

Over time the fixes and new features for the Raspberry Pi will continue to appear in the main stream Kernel. However, if you are facing instability or need some specific feature that isn't yet available in the mainline official Linux Kernel, Slackware provides replacement Kernel packages that are built from the Raspberry Pi's Linux Kernel fork.

![](_page_37_Picture_5.jpeg)

Switching to the Raspberry Pi Kernel fork packages is **not** a recommendation, just an option for users who face instability.

## Installing extra Software

Slackware comes with a good base of software applications, but there are plenty more available in the Open Source Ecosystem.

The best way to add new software is to use the build scripts from SlackBuilds.org.

## Using the Serial/UART adapter

This documentation discusses using the Raspberry Pi without the UART/Serial console.

If you'd like to use one, there are two that have been tested.

#### USB Serial Device converter: Prolific Technology Inc / PL2303

This image below shows the PL2302 (the Serial adapter listed in the Hardware table at the head of this document) connected to the Raspberry Pi:

2024/05/01 11:19 (UTC)

39/40

![](_page_38_Picture_3.jpeg)

#### USB Serial Device converter: FTDI / FT232RL

This is the model shown here.

![](_page_38_Picture_6.jpeg)

#### Using the USB Serial Device converter on the Linux Host Computer

Once wired up, connect the USB end of the adapter into your Linux Host Computer, and use the following command.

![](_page_38_Picture_9.jpeg)

This assumes that there are no other similar adapters occupying /dev/ttyUSB0. If so, you will need to adjust the device name accordingly (e.g. perhaps /dev/ttyUSB1).

screen -T screen-256color /dev/ttyUSB0 115200

## **Known Limitations / Bugs**

Issue	Work around	Notes
General fragility/instability	Transition to the Raspberry Pi Kernel fork packages	

## **Contributing to the Slackware ARM project**

There are a plethora of ARM devices on the market which requires initial R&D and continuous testing. If you'd like to help Slackware support more ARM boards, please check out the documentation explaining how to get involved.

## Supporting / Sponsoring the Slackware ARM project

Maintenance of the Slackware ARM port takes not only a lot of time, but also has financial costs such as the on-going use of electricity, Internet hosting and purchasing and maintenance of ARM hardware.

Once you find yourself enjoying using the ARM port of Slackware, please take a few moments to show your appreciation through sponsorship.

## References

**RPI GPIO exposition** 

RPi4 GPIO pin layout (credit: Les Pounder

Adafruit RTC wiring documentation

From: https://docs.slackware.com/ - **SlackDocs** 

Permanent link: https://docs.slackware.com/slackwarearm:inst\_sa64\_bcm2711\_rpi4

![](_page_39_Picture_14.jpeg)

Last update: 2024/04/30 14:59 (UTC)